



# INSTRUCTIONS

## for CSII LOCK CORE REMOVAL

---

<u>Quantity</u>	<u>Description</u>	<u>PART No.</u>	
1	Core Removal Key	Q618	
1	Lock Core with Key (s)	CALL	

---

### Pedestal Removal Directions:

1. Using the normal key, turn the Lock fully to the locked position. **NOTE:** Lock core will not come out of the cylinder if the Lock is not in this position.
2. Remove the normal key and insert the Lock Core Change Key.
3. Turn slightly counter-clockwise and pull the lock core out from the cylinder body.

### Overhead Flipper Door Removal Directions:

1. Using the normal key, turn the Lock fully to the unlocked position. **NOTE:** Lock core will not come out of the cylinder if the Lock is not in this position.
2. Remove the normal key and insert the Lock Core Change Key.
3. Turn slightly counter-clockwise and pull the lock core out from the cylinder body.

### Installation Directions:

4. Insert the Change Key into the 'NEW' lock plug.
5. Insert the lock core into the cylinder body.

OVERHEAD UNIT: NEW plug must be inserted with the Lock Code on the Left Side of Lock Core Face.

DRAWER PEDESTAL: NEW plug must be inserted with the Lock Code towards the front of the overhead.

6. Using your finger to retain the lock plug in the cylinder body, remove the Change Key.
7. The lock is ready for normal use.



© Mayline Company, LLC  
619 N. Commerce, P.O. Box 728  
Sheboygan, WI 53082-0728  
Toll Free: 1-800-822-8037  
FAX: 920-457-7388  
On Line: [www.mayline.com](http://www.mayline.com)