
ASSEMBLY INSTRUCTIONS Mercado Mesh Back Chair **Model No. 3200**






101719 Cylinder Cover

PARTS LIST 3200


When ordering components, specific color and/or size information may be required. Contact a Mayline Customer Service Representative. 1-800-822-8037

4 * Individual Items, Order by part number.
** Denotes Color Code. Reference Letter 101724 Arm Knob


N




|--|




- 1. Place Base (F) upside down and push Casters (E) firmly into base. 5
- Turn Base right side up and insert Cylinder (G) into center hole of Base.
 Place Cylinder Cover (H) over Cylinder.




4. Assemble Mechanism (D) to Seat (B) using Screws (L), Lock Washer (N) & Washer (P) 4 places as shown.




5. Assemble Back (A) onto Mechanism (D) using Screws (K), Lock Washer (N) & Washer (M) 3 places as shown.



arm. 4. Assemble Arms (C) 2 places onto Seat (B) using Knobs (J) 1 place each





NOTE:

Periodically (Every 90 days) make sure screws are fully tightened.

OPERATING INSTRUCTIONS FOR SYNCHRO-TILT MECHANISM Synchro-Tilt allows the back to tilt 2 degrees for every 1 degree of seat tilt.

1. Seat Height Adjustment.

To raise the seat, pull lever upward and raise your body up slightly to allow the chair to rise to the desired height.

To lower the seat, pull lever upward and apply weight downward on the seat.

2. Seat Tilt Adjustment Lock

Pull lever upward and allow the chair to tilt backwards.
To lock to the desired position push lever downward.
To release tilt adjustment, pull lever upward, apply weight onto the back cushion and then lean forward.

3. Tilt Tension Control Knob.

Turn knob clockwise to increase tilt tension.
Turn knob counter-clockwise to decrease tilt tension.

