


PC Desk w/ Arch Legs



Model No. 971






ASSEMBLY INSTRUCTIONS

CALL 1-800-822-8037 FOR ASSISTANCE




PARTS LIST



Name	Part	Qty.	Spare Qty.
A	 Flat HD Machine Screw M6x65mm HB	16	1
B	 Caster Non Locking HB	2	

Items with HB are in the hardware box.



Name	Part	Qty.	Spare Qty.
C	 Caster Locking HB	2	
	Tools Required (Not Included)  #2 Phillips Screwdriver		
	 Replacement Hdwr Box 971HB		

PARTS LIST

Name	Part	Qty.
D	 971D Arched Leg	2
E	 971E** Bottom Shelf	1
F	 971F*** Cross panel	1

Name	Part	Qty.
G	 971G*** Top	1
H	 971H*** Top Shelf	1

**Denotes Color Code




**DO NOT FULLY TIGHTEN
SCREWS AT THIS TIME**


2

3

3



4



4