















Cart, File - Letter/Legal Model No. FC1010








ASSEMBLY INSTRUCTIONS
CALL 1-800-822-8037 FOR ASSISTANCE



PARTS LIST

Name	Part	Qty.	Name	Part	Qty.
A	 FC1010A Top	1	F1	 FC1010F1 Right Door	1
B1	 FC1010B1 Left Panel	1	F2	 FC1010F2 Left Door	1
B2	 FC1010B2 Right Panel	1	G	 FC1010G Metal Back Panel	1
C	 FC1010C Wood Back Panel	2	H	 FC1010H Bottom Panel	1
D	 XC1010D Leg	2	I	 FC1010I Adjustable Shelf	2
E	 Door Retainer	2	J2	 XC1010J2 Door Handle	2

items with HB are in the hardware box.


PARTS LIST

Name	Part	Qty.
K	 FC1010K Support Bar	2
L	 FC1010L Cross Bar	1
M	 XC1010M Folder Divider	6
N	 XC1010N Door Hinge	4
O1	 XC1010O1 Locking Caster	2
O2	 XC1010O2 Non Locking Caster	2
P	 HB Shelf Pin	9
Q	 HB 1/4 x 75mm	5
S	 HB 1/4 x 10mm	27


Name	Part	Qty.
T	 HB M4 x 10mm	13
U	 HB M4 x 15mm	17
V	 HB Cam Post	13
W	 HB Wood Dowel	9
X	 HB Cam Lock	13
Y	 HB Hex Wrench	1
Z	 HB XC1010Z-Leg Cap	4
AA	 HB 1/4-20 x 2" Flat HD	8
AB	 HB 1/4" x 1" Fender Washer	8
AC	 HB 1/4-20 Lock Nut	8

Items with HB are in the hardware box.


1



2




3




3


4




5




6




7




8



9




10




11

NOTE: DO NOT TIGHTEN.



12



NOTE: TIGHTEN SCREWS.

13

